

Testprocedure for CVR and FDR

CVR 4 Channel operational test:

1. Connect a Headset to the CVR Panel Headset Jack
2. Monitor that audio of the area mike is heard thru the headset
3. Speak into boom mike of captain , F/O and Observer (without pressing PTT) and make sure that this audio is heard thru the headset
4. Make sure that also all audio coming from the selected COMs and NAV's is heard thru the headset for every station.
5. Press test button and monitor for test indication
6. Disconnect headset

FDR Readout:

1. Perform a FDR Readout acc the Manufactureres CMM
2. Route readout to Lab where the following Conditions will be confirmed:
 - a. All required parameters are being recorded
 - b. All Parameter are within reasonable ranges
 - c. a complete flight has been analyzed and all values are determined to occur as expected